



Stihl MSA70CB Battery-Powered Chainsaw Kit 12"

[Read More](#)

SKU: MSA70CB

Categories: [Stihl](#)

Product Description

Stihl MSA70CB Battery-Powered Chainsaw Kit 12"

With an updated design, the MSA 70 C-B delivers excellent performance in a lightweight chainsaw that works alongside you to help maintain your yard. Get the job done faster with the Quick Chain Adjuster that allows you to adjust chain tension on the spot and experience smooth cutting with the OILOMATIC® STIHL PICCO™ Micro™ 3 saw chain. The MSA 70 C-B features a variable-speed trigger, can run for up to 45 minutes when paired with the AK 30 and packs plenty of power for general yard maintenance and firewood cutting.

- **Ematic™ Lubrication System -**

The Ematic™ guide bar, when used with STIHL OILOMATIC® saw chain, will provide proper lubrication and less oil consumption than conventional methods. The system works because two ramps, strategically placed in the guide bar rail, help contain the flow of oil and direct all lubrication to the sliding faces of the bar and chain links as well as the rivets and driver holes, which in turn can reduce bar oil consumption up to 50%.

- **STIHL Electric Motor -**

Lightweight and compact, STIHL electric motors require minimal maintenance and feature low noise levels and reduced vibration.

- **Quick Chain Adjuster (QCA) (B) -**

The Quick Chain Adjuster **(QCA) (B)** allows the user to adjust the tension of the chain without the use of tools. This allows for easy chain adjustment.

Translucent Bar and Chain Oil Tank -

The translucent bar and chain oil tank makes it easy for users to check oil levels at a glance.

- **Lightweight Portability -**

This product is lightweight for easy portability, great maneuverability, and extended use.

- **Rubberized Soft-Touch Handle -**

Soft rubber texture is both easy to grip and makes the product comfortable to hold for extended periods.

- **Variable-Speed Trigger -**

The variable-speed trigger allows precise control for each task.

- **Throttle Trigger Interlock -**

This safety feature must be depressed before the trigger can be activated.

- **STIHL Quickstop® -**

STIHL chainsaws are equipped with a chain stopping system designed to reduce the risk of injury in certain kickback situations. It is called a STIHL Quickstop® chain brake. The STIHL Quickstop® chain brake is designed to stop the rotation of the chain if activated by the operator's hand or by inertia if the saw kicks back with sufficient force. In some working positions, the STIHL Quickstop® chain brake can be activated by inertia, stopping the chain within fractions of a second.

- **Made in America -**

A majority of STIHL products sold in America are made in America of U.S. and global materials.
